

Important Safeguards and Warnings

Operation Requirements



- Use the standard power adapter according to the device label. We will assume no responsibility for any problems caused by the use of a nonstandard power adapter.
- Do not aim the lens at intense light sources, including sunlight and incandescent light to avoid the lens becoming damaged.
- Transport, use and store the device under allowed humidity and temperature conditions.
- Do not place the device in a humid, dusty, extremely hot or cold site that has strong electromagnetic radiation or unstable illumination.
- Prevent liquid from flowing into the device to avoid damage to its internal components.
- Avoid heavy stress, violent vibration, and immersion during transportation, store and installation.

Maintenance Requirements



- Do not disassemble the device without professional instruction.
- The dome cover is an optical component. Do not directly touch the photosensitive CMOS. Use an air blower to clean the dust or dirt on the lens.